

INSTALLATION INSTRUCTIONS


MODELS: TS3636XX **TS4242XX** TS4836XX

WARNING!!!






- 1.) Use this unit only in the manner intended by the manufacturer. If you have any questions, contact the manufacture.
- 2.) Installation work must be performed by qualified personell in accordance with all applicable local and federal regulations.
- 3.) Personell should always follow their company safety procedures at all times.
- 4.) Never use electric tools or have an open flame near volatile petroleum vapors or cleaning agents. Failure to do so, could result in serious injury or death.



DRY-FIT SUMP CANOPY AND TWIST-LOK ACCESS COVER ONTO SUMP RISER.

MEASURE DISTANCE FROM GRADE TO THE TOP OF TWIST-LOK ACCESS COVER.

IF NECESSARY, CUT SUMP RISER SO THAT SUMP LID IS 2 - 6" BELOW THE BOTTOM OF THE MANHOLE COVER.



SAND AND WIPE CLEAN OUTSIDE SURFACES 3" FROM SEAM.

INSTALL 3 LAYERS OF FIBERGLASS OVER SEAM USING MINIMUM 1" OVERLAP. STAGGER EACH LAYER.

AFTER FIBERGLASS HARDENS, APPLY A COAT OF GELCOAT TO FILL ANY PINHOLES.



INSTALL ALL PLUMBING AND ELECTRICAL WIRING, PER MANUFACTURER'S INSTRUCTIONS.

SAND AND WIPE CLEAN THE OUTSIDE SURFACE OF THE TOP 3" OF THE SUMP BASE.


SAND AND WIPE CLEAN THE INSIDE SURFACE OF THE CANOPY

POSITION THE CANOPY ONTO THE SUMP BASE.

MIX FIBERGLASS PUTTY AND CATALYST PER THE LABELED INSTRUCTIONS.

FILL THE GAP BETWEEN THE CANOPY AND THE SUMP BASE WITH FIBERGLASS PUTTY.

ALLOW PUTTY TO HARDEN.



AFTER FIBERGLASS CURES, REMOVE THE TWIST-LOK ACCESS COVER.

CLEAN GASKET AND MATING SURFACE OF THE RISER.

APPLY TWIST-LOK LID DRY LUBRICANT TO GASKET.

INSTALL LID BY TWISTING CLOCKWISE UNTIL HARD STOPS TOUCH.